

## Septic Tank Divider Installation Instructions

### To install Divider panels:

1. Insert Outer Panel through access opening closest to outlet end of tank.
2. Apply silicone sealant to outer edges and bottoms of panels.
3. Slide panels into tank rib as indicated on drawings AST-1000-2, AST-1250-2, and AST-1500-2.
4. Insert Center Panel through access opening.
5. Apply silicone sealant to outer edges and bottom.
6. Engage tangs on center panel with slots on outer panel and push down.
7. Lock panel into place with one 1/4" x 2-1/2" hex bolt, washers and lock nut.

